



| Model | A1 | A2 | X1 | X2 | Y1 | Y2 | B1 | B2 | C1 | C2 | D | H |
|-------------|------|------|---------|---------|---------|---------|-----|-----|---------|---------|-----|------|
| KDD 75x90 | 750 | 900 | 736-746 | 886-896 | 717-727 | 867-877 | 520 | 620 | 207-217 | 257-267 | 805 | 1850 |
| KDD 80x80 | 800 | 800 | 786-796 | 786-796 | 767-777 | 767-777 | 520 | 520 | 257-267 | 257-267 | 740 | 1850 |
| KDD 80x90 | 800 | 900 | 786-796 | 886-896 | 767-777 | 867-877 | 520 | 620 | 257-267 | 257-267 | 805 | 1850 |
| KDD 80x100 | 800 | 1000 | 786-796 | 986-996 | 767-777 | 967-977 | 520 | 620 | 257-267 | 357-367 | 805 | 1850 |
| KDD 90x75 | 900 | 750 | 886-896 | 736-746 | 867-877 | 717-727 | 620 | 520 | 257-267 | 207-217 | 805 | 1850 |
| KDD 90x80 | 900 | 800 | 886-896 | 786-796 | 867-877 | 767-777 | 620 | 520 | 257-267 | 257-267 | 805 | 1850 |
| KDD 90x90 | 900 | 900 | 886-896 | 886-896 | 867-877 | 867-877 | 620 | 620 | 257-267 | 257-267 | 880 | 1850 |
| KDD 90x100 | 900 | 1000 | 886-896 | 986-996 | 867-877 | 967-977 | 620 | 620 | 257-267 | 357-367 | 880 | 1850 |
| KDD 100x80 | 1000 | 800 | 986-996 | 786-796 | 967-977 | 767-777 | 620 | 520 | 357-367 | 257-267 | 805 | 1850 |
| KDD 100x90 | 1000 | 900 | 986-996 | 886-896 | 967-977 | 867-877 | 620 | 620 | 357-367 | 257-267 | 880 | 1850 |
| KDD 100x100 | 1000 | 1000 | 986-996 | 986-996 | 967-977 | 967-977 | 620 | 620 | 357-367 | 357-367 | 880 | 1850 |